



How to clean the Nikon Coolpix S8200 shutter

Cleaning of the Shutter and Lens

Written By: Nelson Antiposti





Step 1 — How to clean the Nikon Coolpix S8200 shutter




- First, you must unscrew the back part of the case off. This requires you to unscrew the screws on the bottom, left, and right side. Be careful, there are parts that have hidden screws under flippable parts, like this one.

Step 2



- You do not have to completely remove the back of the camera. Leaving it like this is fine.
- Once the back has been taken off, remove the screws that will be able to take off the front.

Step 3



- Once the front casing has been removed, this is what you will see. Get a q-tip, dip it in some rubbing alcohol or water, and begin to wipe away the residue, you can part the shutters and clean the lens as well.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-17 03:11:36 PM.